## **Assembly manual**

## catalog

1 Assenbly frame	3
2 Assembly X axis and Y axis	31
3 Assembly Z axis	90
4 Assembly Y siwtch and Z switch	129
5 Assembly feeder motor	139
6 Assembly board, LCD and power supply	152
7 Connect cable	167

Thank you for your kind support to choose our product!

When you use the printer, meet some problems, pls contact us.

Email: FlsunService@163.com

Skype: FLSUN Technical Support

pls visit the Facebook group, many people could help solve problem and

share ideas.

the Facebook group link as follow:

https://touch.facebook.com/groups/511992158981791?ref=bookmarks

1,If you are satisfied with Kossel 3d printer kits, please leave a positive

feedback to us, thank you so much for your kindness.


2, If you are not satisfied for any reason, please contact us before leaving


a negative feedback(any negative review no longer be changed again), we

will work together with you to help you solve any problem until you are


satisfied


## key parts show

































































































































## 2 Assembly X axis and Y axis

























































































































## Overlooking, this angle !!!








































## Install the auto leveling sensor




















The temperature sensor is inserted into the specified hole, the screw is pressed against one of the threads, then firmly fix the screw, taking care not to damage the temperature sensor




Insert the heating bar into the specified hole








Then firmly fix the screw





these rod maybe not absolute 500mm, maybe 500mm±3mm, it's no problem and no matter, the rod only support moving.


















these rod maybe not absolute 400mm, maybe 400mm ± 5mm, it's no problem and no matter.
for these two rods,400mm is enough long.
400 mm rod




















































































































## 3 Assembly Z axis

in order to make it convenient and clearly to assembly Z and plate. we definy the front and back, now, this angle is front, it's important. from front angle, can see the fan and X motor directly.



































the yellow round center to the adge, one is long, another is short. when the rod go through the bearing, the long must be put inside and the short must be put outside.














































































































































## 4 Assembly Y siwtch and Z switch


If you have installed an auto leveling sensor, you can not install the Z-axis limit switch, The Z-axis limit switch is only suitable for manual leveling




















































## **5 Assembly feeder motor**




































































## 6 Assembly board, LCD and power supply










































































## If you are equipped with a touch screen






You can install it in any suitable place.(In the case where the length of the cable is allowed)













when use power, the safe is the most important!!! dont connect AC(110V or 220 V) to board directly. it's right connect the board to power, connect the board must be 12V.




$$\begin{array}{ccc}
123 & + \\
456 & - \\
7 & - & & & & & & \\
89 & - & & & & & & \\
\end{array}$$


## 7 Connect cable





- 1,prohibit connect the AC (110V or 220V) to board directly, it's very dangerous. the board should connect to switch power (12V output).
- 2,the board connect to switch power, "+" must connect to switch power "+", "-" must connect to to "-". this must connect be right, if not, the board will be damaged.
- 3,the fan must be always working,the fan cool the hotend,if not work,will block the nozzle, can not print.
- 4,two temp sersors(nozzle temp sensor and heated bed temp sersor) must connect well,the printer can work.
- 5, for LCD, must exp1 connect to exp1, exp2 connect to exp2.
- 6, for heated bed, can connect to board, also can connect to power directly.
- 7,heat rod,heated bed,temp sensor dont distinguish"+" and "-". power supply and fan must distinguish"+" and "-".


If you are using a manual leveling, the installation of a Z-axis limit switch, you should disconnect the automatic sensor from the main board and insert the Z-axis limit switch occupy its jack.






































































## key parts show



After assembly, please refer to the user manual for the printer to debug and print

